



E-Module VERSION 1.X



| FUSE | CIRCUIT                         |
|------|---------------------------------|
| F1   | Lighting                        |
| F2   | Left side power rial            |
| F3   | Right side power rial           |
| F4   | Controlpanel usb, battery meter |
| F5   | Diesel heater                   |
| F6   | Solar charger                   |
| F7   | Slide out step                  |
| F8   | Outside side LED bar            |
| F9   | Alternator charger              |

| FUSE | CIRCUIT                                |
|------|----------------------------------------|
| F13  | Main fuse fuse box 60A                 |
| F10  | Fuse auxillary charger (300AH version) |